

NAC&ZAC

Cargo Liner Care and Installation Guide

Care Instructions:

- Machine wash gentle.
- Wash separately, dark color.
- Do not bleach.
- Line dry.
- Do not tumble dry.
- Do not Iron.
- Do not dry clean.

Installation:



1. Loop the straps around the headrests and adjust the length of the strips to the best fit.



2. Lay the liner on the cargo area, and fold the bumper flap under the liner.



3. Extends the bumper flap down to protect your bumper when loading and unloading.



4. Loop the straps around the headrests of the front seats when you put down the back seat.